

## **Making Chromerge**

- 1.) In a large beaker carefully add 500mL of concentrated sulfuric acid.
- 2.) Heat to 40°C on a hot plate.
- 3.) Add Chromerge solution slowly to acid under stirring
- 4.) Upon Addition of Chromerge a precipitate will form, keep adding only after precipitate dissolves.
- 5.) Once all Chromerge solution has been added remove from heat and stop stirring. Store Chromerge in glass bottle tightly sealed.